

HOW TO SAFELY DISPOSE/RECYCLE YOUR EMPTY BALLOON TIME® TANK

SUPPLIES

- Hammer
- Flat-head screwdriver
- Protective gloves and eyewear
- Permanent marker

INSTRUCTIONS

- 1) Fully open the green valve by turning counter-clockwise until it stops.
- 2) Push down on the black tilt nozzle until hissing sound stops to release all pressure.
- 3) Remove the tilt nozzle by turning the white valve nut counter-clockwise.
- 4) Your Balloon Time tank should now look like this.
- 5) Put on protective gloves and eyewear. Using a hammer and flat-head screwdriver, puncture the side of the small relief disc on the back of the shoulder, and pry open. You may have to puncture the ring in a few places around the disc to fully remove.
- 6) Remove the disc by hand. Edges may be sharp, so wear gloves and use caution.
- 7) Circle the open hole and write "Empty" on the tank.
- 8) Dispose of in the regular trash or as scrap metal recycling.

**DO NOT BRING HELIUM TANKS TO THE MCMUA
HHW FACILITY OR AT EVENT DISPOSAL DAYS.**

VISIT THE MCMUA WEBPAGE FOR MORE INFORMATION AT:
MCMUA.COM/SW_HHW.ASP

