

# HOW TO SAFELY DISPOSE/RECYCLE YOUR EMPTY BALLOON TIME® TANK

## SUPPLIES

- Hammer
- Flat-head screwdriver
- Protective gloves and eyewear
- Permanent marker

## INSTRUCTIONS

- 1) Fully open the green valve by turning it counterclockwise until it stops.
- 2) To release all pressure, push down on the black tilt nozzle until the hissing sound stops.
- 3) Remove the tilted nozzle by turning the white valve nut counterclockwise.
- 4) Put on protective gloves and eyewear. Then, using a hammer and flat-head screwdriver, puncture the side of the small relief disc on the back of the shoulder and pry it open. You may have to puncture the ring in a few places around the disc to remove it entirely.
- 5) Remove the disc by hand. Edges may be sharp, so wear gloves and use caution.
- 6) Circle the open hole and write "Empty" on the tank.
- 7) Dispose of the tank in the regular trash or as scrap metal recycling when empty.

**ALWAYS FOLLOW THE PRODUCT'S LABEL AND  
MANUFACTURER'S INSTRUCTIONS**

**HELIUM TANKS ARE NOT ACCEPTED AT THE  
MCMUA HHW FACILITY, AT THE HHW EVENT  
DISPOSAL DAYS, OR IN YOUR CURBSIDE  
RECYCLING BIN.**

**VISIT [WWW.MCMUA.COM](http://WWW.MCMUA.COM) FOR MORE INFORMATION**

M O R R I S C O U N T Y



MUNICIPAL UTILITIES AUTHORITY



REV. 02/23